

swiss G11 BIPOD ADAPTER



This G11 rail type Bipod Adapter for the G11 series rifle may only be used together with the G11 Bolt on Scope Mount.

Remove the front screw that attaches the G11 mount to the rifle. Do not loosen the rear screw. Align the hole at the back of the bipod rail with the hole at the front of the G11 mount. First, rotate the yoke up into the stock using simply hand pressure. Do not use any object to "tap" the yoke up into the stock. Now replace the new screw through the bipod rail anchor and back through the G11 mount and tighten into the rifle. check your scopeto make sure the point of aim/impact did not change.

www.swissproductsusa.com